

Servicing Outdoor Power Equipment Dealers Since 1984
8 McFadden Road © Easton, PA 18045 © (800) 942-2326 © https://shop.cadcodist.com/

## **Stinger Quad AER Seed Box Adjustment**

There are three points of adjustment when a seed gate is making contact with the seed box.

- 1. On each side of the unit loosen the three nuts outlined in red, the 2 nuts outlined blue and the two nuts outlined in green.
- 2. Occasionally the seed chute sticks on a bolt head and can be push down and back slightly. Retighten the green bolts on both sides once the chute is all the way back and down.
- 3. Push down on the box support brackets. Once they have bottomed out tighten the nuts outlined in blue (both sides).
- 4. Finally lift up on the seedbox and tighten the nuts outlined in red. There is a small amount of play in the seedbox and supports that when utilized can provide *additional clearance for the seedgate*.

